



Cross Reference Apache vs. Crown

Updated 11-29-11 by JMK

<u>Absorba Mat</u>	<u>Super-Soaker</u>
<u>Apache Grip</u>	<u>Laundry Mat</u>
<u>Apache Rib</u>	<u>Needle-Rib</u>
<u>Apachestat Soft Foot</u>	<u>Comfort-King Anti-Static</u>
<u>Apachestat Smooth Tech</u>	<u>Stat-Control</u>
<u>Armor Step</u>	<u>Wear-Bonded Tuff-Spun</u>
<u>Brush & Clean</u>	<u>Cross-Over</u>
<u>Brush Loop</u>	<u>Fore-Runner</u>
<u>Bubble Flex</u>	<u>Yoga-Flex</u>
<u>Chevron Rib</u>	<u>Chevron</u>
<u>Clean Grip</u>	<u>Crown-Tred</u>
<u>Clean Loop</u>	<u>Walk-Away</u>
<u>Conductive Diamond Foot</u>	<u>Electrically Conductive Deck Plate</u>
<u>Counter Tred</u>	<u>no equivalent, old Nyra Cord</u>
<u>Cushion Foot</u>	<u>Yoga-Flex</u>
<u>Diamond Foot</u>	<u>9/16" Industrial Deck Plate</u>
<u>Diamond Runner</u>	<u>Deck Plate Runner</u>
<u>Duro Rib</u>	<u>Needle Pin</u>
<u>Ergo Flex</u>	<u>Wear-Bonded Tuff-Spun</u>
<u>Gatekeeper</u>	<u>Super-Soaker / Super-Soaker Diamond</u>
<u>Grid Step</u>	<u>Cushion Tile</u>
<u>Invigorator</u>	<u>Sta-Kleen Anti-Fatigue</u>
<u>Knee Saver</u>	<u>Kneelers</u>
<u>Looper, The</u>	<u>Fore-Runner</u>
<u>Lustre Twist</u>	<u>Wonder-Pro</u>
<u>Marble Foot / K-Marble Foot</u>	<u>Cushion Step Marbleized Rubber</u>
<u>Maxima</u>	<u>Dura-Dot singed on all sides</u>
<u>Maxima Edge</u>	<u>Dura-Dot with HD nosing on all sides</u>
<u>Mega-Loop Unbacked</u>	<u>Spaghetti Mat, unbacked</u>
<u>Mega-Loop, Backed</u>	<u>Spaghetti Mat, backed</u>
<u>Mission</u>	<u>Crown-Tred</u>
<u>Noyz Mat</u>	<u>Dura Shock</u>
<u>Performa</u>	<u>Safety-Step Perforated</u>
<u>Performa w/ Grit-Tuff</u>	<u>Dura-Step II w/ Grit</u>
<u>Performa SD</u>	<u>Ergo X-Treme w/ Grit</u>
<u>Perma-Walk</u>	<u>no equivalent, old Nyra-Cord Perma-Walk</u>
<u>Plush Tuff Olefin / Plush Tuff Olefin Solids</u>	<u>Wonder-Pro</u>
<u>Prestige</u>	<u>Oxford</u>
<u>Safety Soft Foot</u>	<u>Safe-N-Easy</u>
<u>Safety Tru-Tread</u>	<u>Safewalk w/ colored borders</u>
<u>Soft Foot</u>	<u>Tuff-Spun / Foot-Lover</u>
<u>Stand-N-Weld</u>	<u>Spark Safe</u>
<u>Standard Tuff Olefin</u>	<u>Rely-On-Olefin</u>
<u>Super-Grip</u>	<u>Crown-Tred</u>

Supreme Diamond Foot	7/8" Industrial Deck Plate Ultra
Supreme Slip Tech	<i>Industrial Deck Plate</i>
Supreme Soft Foot	5/8" Super-Sponge
Switchboard Corrugated	Corrugated Switchboard Runner
Switchboard Diamond Deck Plate	Military Deck Plate Switchboard Runner
Switchboard Smooth	Military Smooth Switchboard Runner
Tacky-Mat	Walk-N-Clean
Tire Tuff Royale	Super-Soaker w/ fabric borders
Tire Tuff Elite	Super-Soaker Diamond w/ fabric borders
Tire Tuff Cleanscape	Super-Soaker Diamond w/ fabric borders
Trooper	Finger-Tip
Tru-Tread	Safewalk
Tru-Tread w/ Grit-Tuff	<i>Dura-Step II w/ grit</i>
Tuff Foot Runner	Corec Runner
Ultimate Diamond Foot	<i>Industrial Deck Plate Ultra</i>
Weld-Master	Spark Safe
Work Step	Safewalk-Light in black

- *Italic print indicates the product is not an exact match. Recommended equivalent is for similar application.*
- If product is not listed above, please contact Crown for product recommendation at 1-800-628-5463 or visit our website at www.crown-mats.com for our useful mat finder.